

```

/**
 * Marlin 3D Printer Firmware
 * Copyright (C) 2016 MarlinFirmware
[https://github.com/MarlinFirmware/Marlin]
*
* Based on Sprinter and grbl.
* Copyright (C) 2011 Camiel Gubbels / Erik van der Zalm
*
* This program is free software: you can redistribute it and/or modify
* it under the terms of the GNU General Public License as published by
* the Free Software Foundation, either version 3 of the License, or
* (at your option) any later version.
*
* This program is distributed in the hope that it will be useful,
* but WITHOUT ANY WARRANTY; without even the implied warranty of
* MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
* GNU General Public License for more details.
*
* You should have received a copy of the GNU General Public License
* along with this program. If not, see <http://www.gnu.org/licenses/>.
*
*/

```

```

/**
 * Configuration.h
*
* Basic settings such as:
*
* - Type of electronics
* - Type of temperature sensor
* - Printer geometry
* - Endstop configuration
* - LCD controller
* - Extra features
*
* Advanced settings can be found in Configuration_adv.h
*
*/
#ifndef CONFIGURATION_H
#define CONFIGURATION_H
```

```

/**
*
* **** ATTENTION TO ALL DEVELOPERS ****
* You must increment this version number for every significant change such
as,
* but not limited to: ADD, DELETE RENAME OR REPURPOSE any directive/option.
*
* Note: Update also Version.h !

```

```

*/
#define CONFIGURATION_H_VERSION 010100

//=====
=====

//===== Getting Started
=====

//=====
=====

/***
 * Here are some standard links for getting your machine calibrated:
 *
 * http://reprap.org/wiki/Calibration
 * http://youtu.be/wAL9d7FgInk
 * http://calculator.josefprusa.cz
 * http://reprap.org/wiki/Triffid_Hunter%27s_Calibration_Guide
 * http://www.thingiverse.com/thing:5573
 *
https://sites.google.com/site/repraplogphase/calibration-of-your-repra
p
 * http://www.thingiverse.com/thing:298812
 */

//=====
=====

//===== DELTA Printer
=====

//=====
=====

// For a Delta printer replace the configuration files with the files in
the
// example_configurations/delta directory.
//


//=====
=====

//===== SCARA Printer
=====

//=====
=====

// For a Scara printer replace the configuration files with the files in
the
// example_configurations/SCARA directory.
//


// @section info

// User-specified version info of this build to display in [Prонterface,
etc] terminal window during
// startup. Implementation of an idea by Prof Braino to inform user that
any changes made to this

```

```

// build by the user have been successfully uploaded into firmware.
#define STRING_CONFIG_H_AUTHOR "(none, default config)" // Who made the
changes.
#define SHOW_BOOTSCREEN
#define STRING_SPLASH_LINE1 SHORT_BUILD_VERSION // will be shown during
bootup in line 1
#define STRING_SPLASH_LINE2 WEBSITE_URL // will be shown during
bootup in line 2

//
// *** VENDORS PLEASE READ
***** //

// Marlin now allow you to have a vendor boot image to be displayed on machine
// start. When SHOW_CUSTOM_BOOTSCREEN is defined Marlin will first show
your
// custom boot image and them the default Marlin boot image is shown.
//
// We suggest for you to take advantage of this new feature and keep the
Marlin
// boot image unmodified. For an example have a look at the bq Hephestos
2
// example configuration folder.
//
// #define SHOW_CUSTOM_BOOTSCREEN
// @section machine

// SERIAL_PORT selects which serial port should be used for communication
with the host.
// This allows the connection of wireless adapters (for instance) to
non-default port pins.
// Serial port 0 is still used by the Arduino bootloader regardless of this
setting.
// :[0,1,2,3,4,5,6,7]
#define SERIAL_PORT 0

// This determines the communication speed of the printer
// :[2400,9600,19200,38400,57600,115200,250000]
#define BAUDRATE 250000

// Enable the Bluetooth serial interface on AT90USB devices
// #define BLUETOOTH

// The following define selects which electronics board you have.
// Please choose the name from boards.h that matches your setup
#ifndef MOTHERBOARD
#define MOTHERBOARD BOARD_RUMBA
#endif

// Optional custom name for your RepStrap or other custom machine
// Displayed in the LCD "Ready" message
#define CUSTOM_MACHINE_NAME "XL BigBox"

```

```

// Define this to set a unique identifier for this printer, (Used by some
programs to differentiate between machines)
// You can use an online service to generate a random UUID. (eg
http://www.uuidgenerator.net/version4)
//">#define MACHINE_UUID "00000000-0000-0000-0000-000000000000"

// This defines the number of extruders
// :[1,2,3,4]
#define EXTRUDERS 4

// For Cyclops or any "multi-extruder" that shares a single nozzle.
//">#define SINGLENOZZLE

// A dual extruder that uses a single stepper motor
// Don't forget to set SSDE_SERVO_ANGLES and HOTEND_OFFSET_X/Y/Z
//">#define SWITCHING_EXTRUDER
#if ENABLED(SWITCHING_EXTRUDER)
#define SWITCHING_EXTRUDER_SERVO_NR 0
#define SWITCHING_EXTRUDER_SERVO_ANGLES { 0, 90 } // Angles for E0, E1
//">#define HOTEND_OFFSET_Z {0.0, 0.0}
#endif

/***
 * "Mixing Extruder"
 * - Adds a new code, M165, to set the current mix factors.
 * - Extends the stepping routines to move multiple steppers in
proportion to the mix.
 * - Optional support for Repetier Host M163, M164, and virtual extruder.
 * - This implementation supports only a single extruder.
 * - Enable DIRECT_MIXING_IN_G1 for Pia Taubert's reference
implementation
*/
//">#define MIXING_EXTRUDER
#if ENABLED(MIXING_EXTRUDER)
#define MIXING_STEPPERS 2           // Number of steppers in your mixing
extruder
#define MIXING_VIRTUAL_TOOLS 16    // Use the Virtual Tool method with M163
and M164
//">#define DIRECT_MIXING_IN_G1     // Allow ABCDHI mix factors in G1
movement commands
#endif

// Offset of the extruders (uncomment if using more than one and relying
on firmware to position when changing).
// The offset has to be X=0, Y=0 for the extruder 0 hotend (default
extruder).
// For the other hotends it is their distance from the extruder 0 hotend.
#define HOTEND_OFFSET_X {0.0, 20.00, 0.0, 20.0} // (in mm) for each
extruder, offset of the hotend on the X axis
#define HOTEND_OFFSET_Y {0.0, 0.0, 20.0, 20.0} // (in mm) for each
extruder, offset of the hotend on the Y axis

```

```

//// The following define selects which power supply you have. Please choose
the one that matches your setup
// 1 = ATX
// 2 = X-Box 360 203Watts (the blue wire connected to PS_ON and the red
wire to VCC)
// :{1:'ATX',2:'X-Box 360'}
#define POWER_SUPPLY 1

// Define this to have the electronics keep the power supply off on startup.
If you don't know what this is leave it.
#define PS_DEFAULT_OFF

// @section temperature

=====
===== Thermal Settings
=====

// ---NORMAL IS 4.7kohm PULLUP!-- 1kohm pullup can be used on hotend sensor,
using correct resistor and table
// 

//// Temperature sensor settings:
// -3 is thermocouple with MAX31855 (only for sensor 0)
// -2 is thermocouple with MAX6675 (only for sensor 0)
// -1 is thermocouple with AD595
// 0 is not used
// 1 is 100k thermistor - best choice for EPCOS 100k (4.7k pullup)
// 2 is 200k thermistor - ATC Semitec 204GT-2 (4.7k pullup)
// 3 is Mendel-parts thermistor (4.7k pullup)
// 4 is 10k thermistor !! do not use it for a hotend. It gives bad resolution
at high temp. !!
// 5 is 100K thermistor - ATC Semitec 104GT-2 (Used in ParCan & J-Head)
(4.7k pullup)
// 6 is 100k EPCOS - Not as accurate as table 1 (created using a fluke
thermocouple) (4.7k pullup)
// 7 is 100k Honeywell thermistor 135-104LAG-J01 (4.7k pullup)
// 71 is 100k Honeywell thermistor 135-104LAF-J01 (4.7k pullup)
// 8 is 100k 0603 SMD Vishay NTCS0603E3104FXT (4.7k pullup)
// 9 is 100k GE Sensing AL03006-58.2K-97-G1 (4.7k pullup)
// 10 is 100k RS thermistor 198-961 (4.7k pullup)
// 11 is 100k beta 3950 1% thermistor (4.7k pullup)
// 12 is 100k 0603 SMD Vishay NTCS0603E3104FXT (4.7k pullup) (calibrated
for Makibox hot bed)
// 13 is 100k Hisens 3950 1% up to 300°C for hotend "Simple ONE" & "Hotend
"All In ONE"
// 20 is the PT100 circuit found in the Ultimainboard V2.x
// 60 is 100k Maker's Tool Works Kapton Bed Thermistor beta=3950
// 66 is 4.7M High Temperature thermistor from Dyze Design

```

```

// 70 is the 100K thermistor found in the bq Hephestos 2
//
//      1k ohm pullup tables - This is not normal, you would have to have
changed out your 4.7k for 1k
//                      (but gives greater accuracy and more stable
PID)
// 51 is 100k thermistor - EPCOS (1k pullup)
// 52 is 200k thermistor - ATC Semitec 204GT-2 (1k pullup)
// 55 is 100k thermistor - ATC Semitec 104GT-2 (Used in ParCan & J-Head)
(1k pullup)
//
// 1047 is Pt1000 with 4k7 pullup
// 1010 is Pt1000 with 1k pullup (non standard)
// 147 is Pt100 with 4k7 pullup
// 110 is Pt100 with 1k pullup (non standard)
// 998 and 999 are Dummy Tables. They will ALWAYS read 25°C or the
temperature defined below.
//      Use it for Testing or Development purposes. NEVER for production
machine.

#define DUMMY_THERMISTOR_998_VALUE 25
#define DUMMY_THERMISTOR_999_VALUE 100
// :{ '0': "Not used",'1':"100k / 4.7k - EPCOS",'2':"200k / 4.7k - ATC
Semitec 204GT-2",'3':"Mendel-parts / 4.7k",'4':"10k !! do not use for a
hotend. Bad resolution at high temp. !!!",'5':"100K / 4.7k - ATC Semitec
104GT-2 (Used in ParCan & J-Head)",'6':"100k / 4.7k EPCOS - Not as accurate
as Table 1",'7':"100k / 4.7k Honeywell 135-104LAG-J01",'8':"100k / 4.7k
0603 SMD Vishay NTCS0603E3104FXT",'9':"100k / 4.7k GE Sensing
AL03006-58.2K-97-G1",'10':"100k / 4.7k RS 198-961",'11':"100k / 4.7k beta
3950 1%",'12':"100k / 4.7k 0603 SMD Vishay NTCS0603E3104FXT (calibrated
for Makibox hot bed)"},'13':"100k Hisens 3950 1% up to 300°C for hotend
'Simple ONE ' & hotend 'All In ONE'",'20':"PT100 (Ultimainboard
V2.x)",'51':"100k / 1k - EPCOS",'52':"200k / 1k - ATC Semitec
204GT-2",'55':"100k / 1k - ATC Semitec 104GT-2 (Used in ParCan &
J-Head)",'60':"100k Maker's Tool Works Kapton Bed Thermistor
beta=3950",'66':"Dyze Design 4.7M High Temperature thermistor",'70':"the
100K thermistor found in the bq Hephestos 2",'71':"100k / 4.7k Honeywell
135-104LAF-J01",'147':"Pt100 / 4.7k",'1047':"Pt1000 / 4.7k",'110':"Pt100
/ 1k (non-standard)"},'1010':"Pt1000 / 1k (non
standard)"},'-3':"Thermocouple + MAX31855 (only for sensor
0)"},'-2':"Thermocouple + MAX6675 (only for sensor 0)"},'-1':"Thermocouple
+ AD595",'998':"Dummy 1",'999':"Dummy 2" }

#define TEMP_SENSOR_0 5
#define TEMP_SENSOR_1 5
#define TEMP_SENSOR_2 5
#define TEMP_SENSOR_3 5
#define TEMP_SENSOR_BED 5

// This makes temp sensor 1 a redundant sensor for sensor 0. If the
temperatures difference between these sensors is to high the print will
be aborted.
#ifndef TEMP_SENSOR_1_AS_REDUNDANT
#define MAX_REDUNDANT_TEMP_SENSOR_DIFF 10

```

```

// Extruder temperature must be close to target for this long before M109
// returns success
#define TEMP_RESIDENCY_TIME 10 // (seconds)
#define TEMP_HYSTERESIS 3 // (degC) range of +/- temperatures
// considered "close" to the target one
#define TEMP_WINDOW 1 // (degC) Window around target to start
// the residency timer x degC early.

// Bed temperature must be close to target for this long before M190 returns
// success
#define TEMP_BED_RESIDENCY_TIME 10 // (seconds)
#define TEMP_BED_HYSTERESIS 3 // (degC) range of +/- temperatures
// considered "close" to the target one
#define TEMP_BED_WINDOW 1 // (degC) Window around target to
// start the residency timer x degC early.

// The minimal temperature defines the temperature below which the heater
// will not be enabled It is used
// to check that the wiring to the thermistor is not broken.
// Otherwise this would lead to the heater being powered on all the time.
#define HEATER_0_MINTEMP 5
#define HEATER_1_MINTEMP 5
#define HEATER_2_MINTEMP 5
#define HEATER_3_MINTEMP 5
#define BED_MINTEMP 5

// When temperature exceeds max temp, your heater will be switched off.
// This feature exists to protect your hotend from overheating
// accidentally, but *NOT* from thermistor short/failure!
// You should use MINTEMP for thermistor short/failure protection.
#define HEATER_0_MAXTEMP 300
#define HEATER_1_MAXTEMP 300
#define HEATER_2_MAXTEMP 300
#define HEATER_3_MAXTEMP 300
#define BED_MAXTEMP 150

//=====
===== PID Settings
=====

// PID Tuning Guide here: http://reprap.org/wiki/PID_Tuning

// Comment the following line to disable PID and enable bang-bang.
#define PIDTEMP
#define BANG_MAX 255 // limits current to nozzle while in bang-bang mode;
// 255=full current
#define PID_MAX_BANG_MAX // limits current to nozzle while PID is active
// (see PID_FUNCTIONAL_RANGE below); 255=full current
#if ENABLED(PIDTEMP)

```

```

//#define PID_AUTOTUNE_MENU // Add PID Autotune to the LCD "Temperature"
menu to run M303 and apply the result.
//#define PID_DEBUG // Sends debug data to the serial port.
//#define PID_OPENLOOP 1 // Puts PID in open loop. M104/M140 sets the
output power from 0 to PID_MAX
//#define SLOW_PWM_HEATERS // PWM with very low frequency (roughly
0.125Hz=8s) and minimum state time of approximately 1s useful for heaters
driven by a relay
//#define PID_PARAMS_PER_HOTEND // Uses separate PID parameters for each
extruder (useful for mismatched extruders)
                                // Set/get with gcode: M301 E[extruder
number, 0-2]
#define PID_FUNCTIONAL_RANGE 10 // If the temperature difference between
the target temperature and the actual temperature
                                // is more than PID_FUNCTIONAL_RANGE
then the PID will be shut off and the heater will be set to min/max.
#define PID_INTEGRAL_DRIVE_MAX PID_MAX //limit for the integral term
#define K1 0.95 //smoothing factor within the PID

// If you are using a pre-configured hotend then you can use one of the
value sets by uncommenting it
// Ultimaker
#define DEFAULT_Kp 22.2
#define DEFAULT_Ki 1.08
#define DEFAULT_Kd 114

// MakerGear
//#define DEFAULT_Kp 7.0
//#define DEFAULT_Ki 0.1
//#define DEFAULT_Kd 12

// Mendel Parts V9 on 12V
//#define DEFAULT_Kp 63.0
//#define DEFAULT_Ki 2.25
//#define DEFAULT_Kd 440

#endif // PIDTEMP

=====
===== PID > Bed Temperature Control
=====
=====

// Select PID or bang-bang with PIDTEMPBED. If bang-bang,
BED_LIMIT_SWITCHING will enable hysteresis
//
// Uncomment this to enable PID on the bed. It uses the same frequency PWM
as the extruder.
// If your PID_dT is the default, and correct for your
hardware/configuration, that means 7.689Hz,
// which is fine for driving a square wave into a resistive load and does

```

```

not significantly impact your FET heating.
// This also works fine on a Fotek SSR-10DA Solid State Relay into a 250W
heater.
// If your configuration is significantly different than this and you don't
understand the issues involved, you probably
// shouldn't use bed PID until someone else verifies your hardware works.
// If this is enabled, find your own PID constants below.
#define PIDTEMPBED

#define BED_LIMIT_SWITCHING

// This sets the max power delivered to the bed, and replaces the
HEATER_BED_DUTY_CYCLE_DIVIDER option.
// all forms of bed control obey this (PID, bang-bang, bang-bang with
hysteresis)
// setting this to anything other than 255 enables a form of PWM to the
bed just like HEATER_BED_DUTY_CYCLE_DIVIDER did,
// so you shouldn't use it unless you are OK with PWM on your bed. (see
the comment on enabling PIDTEMPBED)
#define MAX_BED_POWER 255 // limits duty cycle to bed; 255=full current

#if ENABLED(PIDTEMPBED)

#define PID_BED_DEBUG // Sends debug data to the serial port.

#define PID_BED_INTEGRAL_DRIVE_MAX MAX_BED_POWER //limit for the
integral term

//120V 250W silicone heater into 4mm borosilicate (MendelMax 1.5+)
//from FOPDT model - kp=.39 Tp=405 Tdead=66, Tc set to 79.2, aggressive
factor of .15 (vs .1, 1, 10)
#define DEFAULT_bedKp 10.00
#define DEFAULT_bedKi .023
#define DEFAULT_bedKd 305.4

//120V 250W silicone heater into 4mm borosilicate (MendelMax 1.5+)
//from pidautotune
#define DEFAULT_bedKp 97.1
#define DEFAULT_bedKi 1.41
#define DEFAULT_bedKd 1675.16

// FIND YOUR OWN: "M303 E-1 C8 S90" to run autotune on the bed at 90
degreesC for 8 cycles.
#endif // PIDTEMPBED

// @section extruder

//this prevents dangerous Extruder moves, i.e. if the temperature is under
the limit
//can be software-disabled for whatever purposes by
#define PREVENT_DANGEROUS_EXTRUDE
//if PREVENT_DANGEROUS_EXTRUDE is on, you can still disable (uncomment)

```

```

very long bits of extrusion separately.
#define PREVENT_LENGTHY_EXTRUDE

#define EXTRUDE_MINTEMP 170
#define EXTRUDE_MAXLENGTH (X_MAX_LENGTH+Y_MAX_LENGTH) //prevent
extrusion of very large distances.

//=====
=====
//===== Thermal Runaway Protection
=====
=====

/***
 * Thermal Protection protects your printer from damage and fire if a
 * thermistor falls out or temperature sensors fail in any way.
 *
 * The issue: If a thermistor falls out or a temperature sensor fails,
 * Marlin can no longer sense the actual temperature. Since a disconnected
 * thermistor reads as a low temperature, the firmware will keep the heater
on.
 *
 * If you get "Thermal Runaway" or "Heating failed" errors the
 * details can be tuned in Configuration_adv.h
 */
#define THERMAL_PROTECTION_HOTENDS // Enable thermal protection for all
extruders
#define THERMAL_PROTECTION_BED // Enable thermal protection for the
heated bed

//=====
=====
//===== Mechanical Settings
=====
=====

// @section machine

// Uncomment one of these options to enable CoreXY, CoreXZ, or CoreYZ
kinematics
//#define COREXY
//#define COREXZ
//#define COREYZ

// Enable this option for Toshiba steppers
//#define CONFIG_STEPPERS_TOSHIBA

//=====
=====

```

```

//===== Endstop Settings
=====
//=====
=====

// @section homing

// Specify here all the endstop connectors that are connected to any endstop
// or probe.
// Almost all printers will be using one per axis. Probes will use one or
// more of the
// extra connectors. Leave undefined any used for non-endstop and non-probe
// purposes.
#define USE_XMIN_PLUG
#define USE_YMIN_PLUG
#define USE_ZMIN_PLUG
//#define USE_XMAX_PLUG
//#define USE_YMAX_PLUG
//#define USE_ZMAX_PLUG

// coarse Endstop Settings
#define ENDSTOPPULLUPS // Comment this out (using // at the start of the
line) to disable the endstop pullup resistors

#if DISABLED(ENDSTOPPULLUPS)
    // fine endstop settings: Individual pullups. will be ignored if
ENDSTOPPULLUPS is defined
    //#define ENDSTOPPULLUP_XMAX
    //#define ENDSTOPPULLUP_YMAX
    //#define ENDSTOPPULLUP_ZMAX
    //#define ENDSTOPPULLUP_XMIN
    //#define ENDSTOPPULLUP_YMIN
    //#define ENDSTOPPULLUP_ZMIN
    //#define ENDSTOPPULLUP_ZMIN_PROBE
#endif

// Mechanical endstop with COM to ground and NC to Signal uses "false" here
// (most common setup).
#define X_MIN_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define Y_MIN_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define Z_MIN_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define X_MAX_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define Y_MAX_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define Z_MAX_ENDSTOP_INVERTING false // set to true to invert the logic
of the endstop.
#define Z_MIN_PROBE_ENDSTOP_INVERTING false // set to true to invert the
logic of the endstop.

```

```

//=====
=====
//===== Z Probe Options
=====
=====

//
// Probe Type
// Probes are sensors/switches that are activated / deactivated
before/after use.
//
// Allen Key Probes, Servo Probes, Z-Sled Probes, FIX_MOUNTED_PROBE, etc.
// You must activate one of these to use AUTO_BED_LEVELING_FEATURE below.
//
// Use M851 to set the Z probe vertical offset from the nozzle. Store with
M500.
//

// A Fix-Mounted Probe either doesn't deploy or needs manual deployment.
// For example an inductive probe, or a setup that uses the nozzle to probe.
// An inductive probe must be deactivated to go below
// its trigger-point if hardware endstops are active.
#define FIX_MOUNTED_PROBE

// The BLTouch probe emulates a servo probe.
#define BLTOUCH

// Z Servo Probe, such as an endstop switch on a rotating arm.
#define Z_ENDSTOP_SERVO_NR 0
#define Z_SERVO_ANGLES {70,0} // Z Servo Deploy and Stow angles

// Enable if you have a Z probe mounted on a sled like those designed by
Charles Bell.
#define Z_PROBE_SLED
#define SLED_DOCKING_OFFSET 5 // The extra distance the X axis must travel
to pickup the sled. 0 should be fine but you can push it further if you'd
like.

// Z Probe to nozzle (X,Y) offset, relative to (0, 0).
// X and Y offsets must be integers.
//
// In the following example the X and Y offsets are both positive:
// #define X_PROBE_OFFSET_FROM_EXTRUDER 10
// #define Y_PROBE_OFFSET_FROM_EXTRUDER 10
//
//      +-- BACK ---+
//      |           |
//      L |      (+) P | R <-- probe (20,20)
//      E |           | I
//      F |  (-) N (+) | G <-- nozzle (10,10)

```

```

// T | H
// | (-) | T
// |
// O-- FRONT --+
// (0,0)
#define X_PROBE_OFFSET_FROM_EXTRUDER 10 // X offset: -left +right [of
the nozzle]
#define Y_PROBE_OFFSET_FROM_EXTRUDER 10 // Y offset: -front +behind [the
nozzle]
#define Z_PROBE_OFFSET_FROM_EXTRUDER 0 // Z offset: -below +above [the
nozzle]

// X and Y axis travel speed (mm/m) between probes
#define XY_PROBE_SPEED 8000
// Speed for the first approach when double-probing (with
PROBE_DOUBLE_TOUCH)
#define Z_PROBE_SPEED_FAST HOMING_FEEDRATE_Z
// Speed for the "accurate" probe of each point
#define Z_PROBE_SPEED_SLOW (Z_PROBE_SPEED_FAST / 2)
// Use double touch for probing
//#define PROBE_DOUBLE_TOUCH

//
// Allen Key Probe is defined in the Delta example configurations.
//

// Enable Z_MIN_PROBE_ENDSTOP to use _both_ a Z Probe and a Z-min-endstop
on the same machine.
// With this option the Z_MIN_PROBE_PIN will only be used for probing, never
for homing.
//
// *** PLEASE READ ALL INSTRUCTIONS BELOW FOR SAFETY! ***
//
// To continue using the Z-min-endstop for homing, be sure to disable
Z_SAFE_HOMING.
// Example: To park the head outside the bed area when homing with G28.
//
// To use a separate Z probe, your board must define a Z_MIN_PROBE_PIN.
//
// For a servo-based Z probe, you must set up servo support below, including
// NUM_SERVOS, Z_ENDSTOP_SERVO_NR and Z_SERVO_ANGLES.
//
// - RAMPS 1.3/1.4 boards may be able to use the 5V, GND, and Aux4->D32
pin.
// - Use 5V for powered (usu. inductive) sensors.
// - Otherwise connect:
//   - normally-closed switches to GND and D32.
//   - normally-open switches to 5V and D32.
//
// Normally-closed switches are advised and are the default.
//
// The Z_MIN_PROBE_PIN sets the Arduino pin to use. (See your board's pins

```

```

file.)
// Since the RAMPS Aux4->D32 pin maps directly to the Arduino D32 pin, D32
is the
// default pin for all RAMPS-based boards. Some other boards map
differently.
// To set or change the pin for your board, edit the appropriate pins_XXXXX.h
file.
//
// WARNING:
// Setting the wrong pin may have unexpected and potentially disastrous
consequences.
// Use with caution and do your homework.
//
// #define Z_MIN_PROBE_ENDSTOP

// Enable Z_MIN_PROBEUSES_Z_MIN_ENDSTOP_PIN to use the Z_MIN_PIN for your
Z_MIN_PROBE.
// The Z_MIN_PIN will then be used for both Z-homing and probing.
#define Z_MIN_PROBEUSES_Z_MIN_ENDSTOP_PIN

// To use a probe you must enable one of the two options above!

// This option disables the use of the Z_MIN_PROBE_PIN
// To enable the Z probe pin but disable its use, uncomment the line below.
This only affects a
// Z probe switch if you have a separate Z min endstop also and have activated
Z_MIN_PROBE_ENDSTOP above.
// If you're using the Z MIN endstop connector for your Z probe, this has
no effect.
// #define DISABLE_Z_MIN_PROBE_ENDSTOP

// Enable Z Probe Repeatability test to see how accurate your probe is
// #define Z_MIN_PROBE_REPEATABILITY_TEST

//
// Probe Raise options provide clearance for the probe to deploy, stow,
and travel.
//
#define Z_PROBE_DEPLOY_HEIGHT 15 // Raise to make room for the probe to
deploy / stow
#define Z_PROBE_TRAVEL_HEIGHT 5 // Raise between probing points.

//
// For M851 give a range for adjusting the Z probe offset
//
#define Z_PROBE_OFFSET_RANGE_MIN -20
#define Z_PROBE_OFFSET_RANGE_MAX 20

// For Inverting Stepper Enable Pins (Active Low) use 0, Non Inverting
(Active High) use 1
// :{0:'Low',1:'High'}
#define X_ENABLE_ON 0

```

```

#define Y_ENABLE_ON 0
#define Z_ENABLE_ON 0
#define E_ENABLE_ON 0 // For all extruders

// Disables axis stepper immediately when it's not being used.
// WARNING: When motors turn off there is a chance of losing position
accuracy!
#define DISABLE_X false
#define DISABLE_Y false
#define DISABLE_Z false
// Warn on display about possibly reduced accuracy
// #define DISABLE_REDUCED_ACCURACY_WARNING

// @section extruder

#define DISABLE_E false // For all extruders
#define DISABLE_INACTIVE_EXTRUDER true // disable only inactive extruders
and keep active extruder enabled

// @section machine

// Invert the stepper direction. Change (or reverse the motor connector)
if an axis goes the wrong way.
#define INVERT_X_DIR false
#define INVERT_Y_DIR true
#define INVERT_Z_DIR false

// @section extruder

// For direct drive extruder v9 set to true, for geared extruder set to
false.
#define INVERT_E0_DIR false
#define INVERT_E1_DIR false
#define INVERT_E2_DIR false
#define INVERT_E3_DIR false

// @section homing

// #define Z_HOMING_HEIGHT 4 // (in mm) Minimal z height before homing
(G28) for Z clearance above the bed, clamps, ...
// Be sure you have this distance over your
Z_MAX_POS in case.

// ENDSTOP SETTINGS:
// Sets direction of endstops when homing; 1=MAX, -1=MIN
// :[-1,1]
#define X_HOME_DIR -1
#define Y_HOME_DIR -1
#define Z_HOME_DIR -1

#define min_software_endstops true // If true, axis won't move to
coordinates less than HOME_POS.

```

```

#define max_software_endstops true // If true, axis won't move to
coordinates greater than the defined lengths below.

// @section machine

// Travel limits after homing (units are in mm)
#define X_MIN_POS 0
#define Y_MIN_POS 0
#define Z_MIN_POS 0
#define X_MAX_POS 200
#define Y_MAX_POS 200
#define Z_MAX_POS 200

//=====
=====

//===== Filament Runout Sensor
=====

//=====

//#define FILAMENT_RUNOUT_SENSOR // Uncomment for defining a filament
runout sensor such as a mechanical or opto endstop to check the existence
of filament
                                // In RAMPS uses servo pin 2. Can be
changed in pins file. For other boards pin definition should be made.
                                // It is assumed that when logic high =
filament available
                                // when logic low
= filament ran out
#if ENABLED(FILAMENT_RUNOUT_SENSOR)
  const bool FIL_RUNOUT_INVERTING = false; // set to true to invert the
logic of the sensor.
  #define ENDSTOPPULLUP_FIL_RUNOUT // Uncomment to use internal pullup for
filament runout pins if the sensor is defined.
  #define FILAMENT_RUNOUT_SCRIPT "M600"
#endif

//=====

//===== Mesh Bed Leveling
=====

//=====

//#define MESH_BED_LEVELING // Enable mesh bed leveling.

#if ENABLED(MESH_BED_LEVELING)
  #define MESH_INSET 10      // Mesh inset margin on print area
  #define MESH_NUM_X_POINTS 3 // Don't use more than 7 points per axis,
implementation limited.
  #define MESH_NUM_Y_POINTS 3
  #define MESH_HOME_SEARCH_Z 4 // Z after Home, bed somewhere below but
above 0.0.

```

```

//#define MESH_G28_REST_ORIGIN // After homing all axes ('G28' or 'G28
XYZ') rest at origin [0,0,0]

//#define MANUAL_BED_LEVELING // Add display menu option for bed
leveling.

#if ENABLED(MANUAL_BED_LEVELING)
  #define MBL_Z_STEP 0.025 // Step size while manually probing Z axis.
#endif // MANUAL_BED_LEVELING

#endif // MESH_BED_LEVELING

//=====
===== Bed Auto Leveling
=====

// @section bedlevel

//#define AUTO_BED_LEVELING_FEATURE // Delete the comment to enable
(remove // at the start of the line)

// Enable this feature to get detailed logging of G28, G29, M48, etc.
// Logging is off by default. Enable this logging feature with 'M111 S32'.
// NOTE: Requires a huge amount of PROGMEM.
//#define DEBUG_LEVELING_FEATURE

#if ENABLED(AUTO_BED_LEVELING_FEATURE)

  // There are 2 different ways to specify probing locations:
  //
  // - "grid" mode
  //   Probe several points in a rectangular grid.
  //   You specify the rectangle and the density of sample points.
  //   This mode is preferred because there are more measurements.
  //
  // - "3-point" mode
  //   Probe 3 arbitrary points on the bed (that aren't collinear)
  //   You specify the XY coordinates of all 3 points.

  // Enable this to sample the bed in a grid (least squares solution).
  // Note: this feature generates 10KB extra code size.
#define AUTO_BED_LEVELING_GRID

#if ENABLED(AUTO_BED_LEVELING_GRID)

  #define LEFT_PROBE_BED_POSITION 15
  #define RIGHT_PROBE_BED_POSITION 170
  #define FRONT_PROBE_BED_POSITION 20

```

```

#define BACK_PROBE_BED_POSITION 170

#define MIN_PROBE_EDGE 10 // The Z probe minimum square sides can be
no smaller than this.

// Set the number of grid points per dimension.
// You probably don't need more than 3 (squared=9).
#define AUTO_BED_LEVELING_GRID_POINTS 2

#else // !AUTO_BED_LEVELING_GRID

// Arbitrary points to probe.
// A simple cross-product is used to estimate the plane of the bed.
#define ABL_PROBE_PT_1_X 15
#define ABL_PROBE_PT_1_Y 180
#define ABL_PROBE_PT_2_X 15
#define ABL_PROBE_PT_2_Y 20
#define ABL_PROBE_PT_3_X 170
#define ABL_PROBE_PT_3_Y 20

#endif // !AUTO_BED_LEVELING_GRID

// #define Z_PROBE_END_SCRIPT "G1 Z10 F12000\nG1 X15 Y330\nG1 Z0.5\nG1
Z10" // These commands will be executed in the end of G29 routine.

// Useful to retract a deployable Z probe.

// If you've enabled AUTO_BED_LEVELING_FEATURE and are using the Z Probe
for Z Homing,
// it is highly recommended you also enable Z_SAFE_HOMING below!

#endif // AUTO_BED_LEVELING_FEATURE

// @section homing

// The center of the bed is at (X=0, Y=0)
#define BED_CENTER_AT_0_0

// Manually set the home position. Leave these undefined for automatic
settings.
// For DELTA this is the top-center of the Cartesian print volume.
#define MANUAL_X_HOME_POS 0
#define MANUAL_Y_HOME_POS 0
#define MANUAL_Z_HOME_POS 0 // Distance between the nozzle to printbed
after homing

// Use "Z Safe Homing" to avoid homing with a Z probe outside the bed area.
//
// With this feature enabled:
//
// - Allow Z homing only after X and Y homing AND stepper drivers still

```

```

enabled.

// - If stepper drivers time out, it will need X and Y homing again before
Z homing.
// - Move the Z probe (or nozzle) to a defined XY point before Z Homing
when homing all axes (G28).
// - Prevent Z homing when the Z probe is outside bed area.
#define Z_SAFE_HOMING

#if ENABLED(Z_SAFE_HOMING)
    #define Z_SAFE_HOMING_X_POINT ((X_MIN_POS + X_MAX_POS) / 2)      // X
point for Z homing when homing all axis (G28).
    #define Z_SAFE_HOMING_Y_POINT ((Y_MIN_POS + Y_MAX_POS) / 2)      // Y
point for Z homing when homing all axis (G28).
#endif

// Homing speeds (mm/m)
#define HOMING_FEEDRATE_XY (50*60)
#define HOMING_FEEDRATE_Z (4*60)

// 
// MOVEMENT SETTINGS
// @section motion
//

// default settings

#define DEFAULT_AXIS_STEPS_PER_UNIT {80,80,4000,500} // default steps
per unit for Ultimaker
#define DEFAULT_MAX_FEEDRATE {300, 300, 5, 25} // (mm/sec)
#define DEFAULT_MAX_ACCELERATION {3000,3000,100,10000} // X, Y,
Z, E maximum start speed for accelerated moves. E default values are good
for Skeinforge 40+, for older versions raise them a lot.

#define DEFAULT_ACCELERATION 3000 // X, Y, Z and E
acceleration in mm/s^2 for printing moves
#define DEFAULT_RETRACT_ACCELERATION 3000 // E acceleration in mm/s^2
for retracts
#define DEFAULT_TRAVEL_ACCELERATION 3000 // X, Y, Z acceleration in
mm/s^2 for travel (non printing) moves

// The speed change that does not require acceleration (i.e. the software
might assume it can be done instantaneously)
#define DEFAULT_XYJERK 20.0 // (mm/sec)
#define DEFAULT_ZJERK 0.4 // (mm/sec)
#define DEFAULT_EJERK 5.0 // (mm/sec)

=====
=====
===== Additional Features
=====
=====
```

```
=====
// @section extras

//
// EEPROM
//
// The microcontroller can store settings in the EEPROM, e.g. max
velocity...
// M500 - stores parameters in EEPROM
// M501 - reads parameters from EEPROM (if you need reset them after you
changed them temporarily).
// M502 - reverts to the default "factory settings". You still need to
store them in EEPROM afterwards if you want to.
//define this to enable EEPROM support
//#define EEPROM_SETTINGS

#if ENABLED(EEPROM_SETTINGS)
    // To disable EEPROM Serial responses and decrease program space by ~1700
byte: comment this out:
    #define EEPROM_CHITCHAT // Please keep turned on if you can.
#endif

//
// Host Keepalive
//
// When enabled Marlin will send a busy status message to the host
// every couple of seconds when it can't accept commands.
//
#define HOST_KEEPALIVE_FEATURE           // Disable this if your host doesn't
like keepalive messages
#define DEFAULT_KEEPALIVE_INTERVAL 2    // Number of seconds between "busy"
messages. Set with M113.

//
// M100 Free Memory Watcher
//
//##define M100_FREE_MEMORY_WATCHER // uncomment to add the M100 Free Memory
Watcher for debug purpose

//
// G20/G21 Inch mode support
//
//##define INCH_MODE_SUPPORT

//
// M149 Set temperature units support
//
//##define TEMPERATURE_UNITS_SUPPORT

// @section temperature
```

```

// Preheat Constants
#define PREHEAT_1_TEMP_HOTEND 180
#define PREHEAT_1_TEMP_BED      70
#define PREHEAT_1_FAN_SPEED     0 // Value from 0 to 255

#define PREHEAT_2_TEMP_HOTEND 240
#define PREHEAT_2_TEMP_BED    110
#define PREHEAT_2_FAN_SPEED    0 // Value from 0 to 255

//  

// Nozzle Park -- EXPERIMENTAL  

//  

// When enabled allows the user to define a special XYZ position, inside  

the  

// machine's topology, to park the nozzle when idle or when receiving the  

G27  

// command.  

//  

// The "P" parameter controls what is the action applied to the Z axis:  

// P0: (Default) If current Z-pos is lower than Z-park then the nozzle  

will  

//          be raised to reach Z-park height.  

//  

// P1: No matter the current Z-pos, the nozzle will be raised/lowered  

to  

//          reach Z-park height.  

//  

// P2: The nozzle height will be raised by Z-park amount but never going  

over  

//          the machine's limit of Z_MAX_POS.  

//  

//#define NOZZLE_PARK_FEATURE

#if ENABLED(NOZZLE_PARK_FEATURE)
  // Specify a park position as { X, Y, Z }
  #define NOZZLE_PARK_POINT { (X_MIN_POS + 10), (Y_MAX_POS - 10), 20 }
#endif

//  

// Clean Nozzle Feature -- EXPERIMENTAL  

//  

// When enabled allows the user to send G12 to start the nozzle cleaning  

// process, the G-Code accepts two parameters:  

//   "P" for pattern selection  

//   "S" for defining the number of strokes/repetitions  

//  

// Available list of patterns:  

//   P0: This is the default pattern, this process requires a sponge type  

//       material at a fixed bed location, the cleaning process is based  

on  

//       "strokes" i.e. back-and-forth movements between the starting and  

end

```

```

//      points.

// P1: This starts a zig-zag pattern between (X0, Y0) and (X1, Y1), "T"
// defines the number of zig-zag triangles to be done. "S" defines
the
//      number of strokes aka one back-and-forth movement. As an example
// sending "G12 P1 S1 T3" will execute:
//
//      --
//      |   (X0, Y1) |   / \   / \   / \   | (X1, Y1)
//      |           |   / \   / \   / \   |
//      A |           |   / \   / \   / \   |
//      |   (X0, Y0) | / \   \ / \   \ / \   | (X1, Y0)
//      -- +-----+-----+-----+
//                  |_____|_____|_____|
//                  T1     T2     T3

// Caveats: End point Z should use the same value as Start point Z.
//
// Attention: This is an EXPERIMENTAL feature, in the future the G-code
arguments
// may change to add new functionality like different wipe patterns.
//
//##define NOZZLE_CLEAN_FEATURE

#if ENABLED(NOZZLE_CLEAN_FEATURE)
  // Number of pattern repetitions
  #define NOZZLE_CLEAN_STROKES 12

  // Specify positions as { X, Y, Z }
  #define NOZZLE_CLEAN_START_POINT { 30, 30, (Z_MIN_POS + 1) }
  #define NOZZLE_CLEAN_END_POINT { 100, 60, (Z_MIN_POS + 1) }

  // Moves the nozzle to the initial position
  #define NOZZLE_CLEAN_GOBACK
#endif

//
// Print job timer
//
// Enable this option to automatically start and stop the
// print job timer when M104/M109/M190 commands are received.
// M104 (extruder without wait) - high temp = none, low temp = stop timer
// M109 (extruder with wait) - high temp = start timer, low temp = stop
timer
// M190 (bed with wait) - high temp = start timer, low temp = none
//
// In all cases the timer can be started and stopped using
// the following commands:
//
// - M75 - Start the print job timer

```

```

// - M76 - Pause the print job timer
// - M77 - Stop the print job timer
#define PRINTJOB_TIMER_AUTOSTART

//
// Print Counter
//
// When enabled Marlin will keep track of some print statistical data such
as:
// - Total print jobs
// - Total successful print jobs
// - Total failed print jobs
// - Total time printing
//
// This information can be viewed by the M78 command.
//#define PRINTCOUNTER

//=====
===== LCD and SD support
=====

// @section lcd

//
// LCD LANGUAGE
//
// Here you may choose the language used by Marlin on the LCD menus, the
following
// list of languages are available:
//   en, an, bg, ca, cn, cz, de, el, el-gr, es, eu, fi, fr, gl, hr, it,
//   kana, kana_utf8, nl, pl, pt, pt_utf8, pt-br, pt-br_utf8, ru, test
//
// {
//   'en': 'English', 'an': 'Aragonese', 'bg': 'Bulgarian', 'ca': 'Catalan', 'cn':
//   'Chinese', 'cz': 'Czech', 'de': 'German', 'el': 'Greek', 'el-gr': 'Greek
//   (Greece)', 'es': 'Spanish', 'eu': 'Basque-Euskera', 'fi': 'Finnish', 'fr': 'Fr
//   ench', 'gl': 'Galician', 'hr': 'Croatian', 'it': 'Italian', 'kana': 'Japanese'
//   , 'kana_utf8': 'Japanese
//   (UTF8)', 'nl': 'Dutch', 'pl': 'Polish', 'pt': 'Portuguese', 'pt-br': 'Portugue
//   se (Brazilian)', 'pt-br_utf8': 'Portuguese (Brazilian
//   UTF8)', 'pt_utf8': 'Portuguese (UTF8)', 'ru': 'Russian', 'test': 'TEST'
//
#define LCD_LANGUAGE en

//
// LCD Character Set
//
// Note: This option is NOT applicable to Graphical Displays.
//

```

```
// All character-based LCD's provide ASCII plus one of these
// language extensions:
//
// - JAPANESE ... the most common
// - WESTERN ... with more accented characters
// - CYRILLIC ... for the Russian language
//
// To determine the language extension installed on your controller:
//
// - Compile and upload with LCD_LANGUAGE set to 'test'
// - Click the controller to view the LCD menu
// - The LCD will display Japanese, Western, or Cyrillic text
//
// See https://github.com/MarlinFirmware/Marlin/wiki/LCD-Language
//
// :['JAPANESE','WESTERN','CYRILLIC']
//
#define DISPLAY_CHARSET_HD44780 JAPANESE

//
// LCD TYPE
//
// You may choose ULTRA_LCD if you have character based LCD with 16x2, 16x4,
20x2,
// 20x4 char/lines or DOGLCD for the full graphics display with 128x64
pixels
// (ST7565R family). (This option will be set automatically for certain
displays.)
//
// IMPORTANT NOTE: The U8glib library is required for Full Graphic Display!
// https://github.com/olikraus/U8glib\_Arduino
//
// #define ULTRA_LCD // Character based
// #define DOGLCD // Full graphics display

//
// SD CARD
//
// SD Card support is disabled by default. If your controller has an SD
slot,
// you must uncomment the following option or it won't work.
//
// #define SDSUPPORT

//
// SD CARD: SPI SPEED
//
// Uncomment ONE of the following items to use a slower SPI transfer
// speed. This is usually required if you're getting volume init errors.
//
// #define SPI_SPEED SPI_HALF_SPEED
// #define SPI_SPEED SPI_QUARTER_SPEED
```

```

// #define SPI_SPEED SPI_EIGHTH_SPEED

//
// SD CARD: ENABLE CRC
//
// Use CRC checks and retries on the SD communication.
//
// #define SD_CHECK_AND_RETRY

//
// ENCODER SETTINGS
//
// This option overrides the default number of encoder pulses needed to
// produce one step. Should be increased for high-resolution encoders.
//
// #define ENCODER_PULSES_PER_STEP 1

//
// Use this option to override the number of step signals required to
// move between next/prev menu items.
//
// #define ENCODER_STEPS_PER_MENU_ITEM 5

/***
 * Encoder Direction Options
 *
 * Test your encoder's behavior first with both options disabled.
 *
 * Reversed Value Edit and Menu Nav? Enable REVERSE_ENCODER_DIRECTION.
 * Reversed Menu Navigation only? Enable REVERSE_MENU_DIRECTION.
 * Reversed Value Editing only? Enable BOTH options.
 */
// This option reverses the encoder direction everywhere
//
// Set this option if CLOCKWISE causes values to DECREASE
//
// #define REVERSE_ENCODER_DIRECTION

//
// This option reverses the encoder direction for navigating LCD menus.
//
// If CLOCKWISE normally moves DOWN this makes it go UP.
// If CLOCKWISE normally moves UP this makes it go DOWN.
//
// #define REVERSE_MENU_DIRECTION

//
// Individual Axis Homing
//
// Add individual axis homing items (Home X, Home Y, and Home Z) to the

```

```
LCD menu.
//
// #define INDIVIDUAL_AXIS_HOMING_MENU

//
// SPEAKER/BUZZER
//
// If you have a speaker that can produce tones, enable it here.
// By default Marlin assumes you have a buzzer with a fixed frequency.
//
// #define SPEAKER

//
// The duration and frequency for the UI feedback sound.
// Set these to 0 to disable audio feedback in the LCD menus.
//
// Note: Test audio output with the G-Code:
// M300 S<frequency Hz> P<duration ms>
//
// #define LCD_FEEDBACK_FREQUENCY_DURATION_MS 100
// #define LCD_FEEDBACK_FREQUENCY_HZ 1000

//
// CONTROLLER TYPE: Standard
//
// Marlin supports a wide variety of controllers.
// Enable one of the following options to specify your controller.
//

//
// Ultimaker Controller.
//
// #define ULTIMAKERCONTROLLER

//
// Ultipanel as seen on Thingiverse.
//
// #define ULTIPANEL

//
// Cartesio UI
// http://mauk.cc/webshop/cartesio-shop/electronics/user-interface
//
// #define CARTESIO_UI

//
// PanelOne from T3P3 (via RAMPS 1.4 AUX2/AUX3)
// http://reprap.org/wiki/PanelOne
//
// #define PANEL_ONE

//
```

```
// MaKr3d Makr-Panel with graphic controller and SD support.
// http://reprap.org/wiki/MaKr3d_MaKrPanel
//
// #define MAKRPANEL

//
// ReprapWorld Graphical LCD
// https://reprapworld.com/?products_details&products_id/1218
//
// #define REPRAPWORLD_GRAPHICAL_LCD

//
// Activate one of these if you have a Panucatt Devices
// Viki 2.0 or mini Viki with Graphic LCD
// http://panucatt.com
//
// #define VIKI2
// #define miniVIKI

//
// Adafruit ST7565 Full Graphic Controller.
// https://github.com/eboston/Adafruit-ST7565-Full-Graphic-Controller/
//
// #define ELB_FULL_GRAPHIC_CONTROLLER

//
// RepRapDiscount Smart Controller.
// http://reprap.org/wiki/RepRapDiscount_Smart_Controller
//
// Note: Usually sold with a white PCB.
//
// #define REPRAP_DISCOUNT_SMART_CONTROLLER

//
// GADGETS3D G3D LCD/SD Controller
// http://reprap.org/wiki/RAMPS_1.3/1.4_GADGETS3D_Shield_with_Panel
//
// Note: Usually sold with a blue PCB.
//
// #define G3D_PANEL

//
// RepRapDiscount FULL GRAPHIC Smart Controller
// http://reprap.org/wiki/RepRapDiscount_Full_Graphic_Smart_Controller
//
// #define REPRAP_DISCOUNT_FULL_GRAPHIC_SMART_CONTROLLER

//
// MakerLab Mini Panel with graphic
// controller and SD support - http://reprap.org/wiki/Mini_panel
//
// #define MINIPANEL
```

```
//  
// RepRapWorld REPRAPWORLD_KEYPAD v1.1  
//  
http://reprapworld.com/?products_details&products_id=202&cPath=1591_16  
26  
//  
// REPRAPWORLD_KEYPAD_MOVE_STEP sets how much should the robot move when  
a key  
// is pressed, a value of 10.0 means 10mm per click.  
//  
//#define REPRAPWORLD_KEYPAD  
//#define REPRAPWORLD_KEYPAD_MOVE_STEP 1.0  
  
//  
// RigidBot Panel V1.0  
// http://www.inventapart.com/  
//  
//#define RIGIDBOT_PANEL  
  
//  
// BQ LCD Smart Controller shipped by  
// default with the BQ Hephestos 2 and Witbox 2.  
//  
//#define BQ_LCD_SMART_CONTROLLER  
  
//  
// CONTROLLER TYPE: I2C  
//  
// Note: These controllers require the installation of Arduino's  
LiquidCrystal_I2C  
// library. For more info:  
https://github.com/kiyoshigawa/LiquidCrystal\_I2C  
//  
  
//  
// Elefu RA Board Control Panel  
// http://www.elefu.com/index.php?route=product/product&product_id=53  
//  
//#define RA_CONTROL_PANEL  
  
//  
// Sainsmart YW Robot (LCM1602) LCD Display  
//  
//#define LCD_I2C_SAINSMART_YWROBOT  
  
//  
// Generic LCM1602 LCD adapter  
//  
//#define LCM1602  
  
//
```

```

// PANELOLU2 LCD with status LEDs,
// separate encoder and click inputs.
//
// Note: This controller requires Arduino's LiquidTWI2 library v1.2.3 or
later.
// For more info: https://github.com/lincomatic/LiquidTWI2
//
// Note: The PANELOLU2 encoder click input can either be directly connected
to
// a pin (if BTN_ENC defined to != -1) or read through I2C (when BTN_ENC
== -1).
//
// #define LCD_I2C_PANELOLU2

//
// Panucatt VIKI LCD with status LEDs,
// integrated click & L/R/U/D buttons, separate encoder inputs.
//
// #define LCD_I2C_VIKI

//
// SSD1306 OLED full graphics generic display
//
// #define U8GLIB_SSD1306

//
// SAV OLEd LCD module support using either SSD1306 or SH1106 based LCD
modules
//
// #define SAV_3DGLCD
#if ENABLED(SAV_3DGLCD)
    // #define U8GLIB_SSD1306
    #define U8GLIB_SH1106
#endif

//
// CONTROLLER TYPE: Shift register panels
//
// 2 wire Non-latching LCD SR from https://goo.gl/aJJ4sH
// LCD configuration: http://reprap.org/wiki/SAV\_3D\_LCD
//
// #define SAV_3DLCD

=====
=====
//===== Extra Features
=====
=====

// @section extras

```

```

// Increase the FAN PWM frequency. Removes the PWM noise but increases
heating in the FET/Arduino
#ifndef FAST_PWM_FAN

// Use software PWM to drive the fan, as for the heaters. This uses a very
low frequency
// which is not as annoying as with the hardware PWM. On the other hand,
if this frequency
// is too low, you should also increment SOFT_PWM_SCALE.
#ifndef FAN_SOFT_PWM

// Incrementing this by 1 will double the software PWM frequency,
// affecting heaters, and the fan if FAN_SOFT_PWM is enabled.
// However, control resolution will be halved for each increment;
// at zero value, there are 128 effective control positions.
#define SOFT_PWM_SCALE 0

// Temperature status LEDs that display the hotend and bed temperature.
// If all hotends and bed temperature and temperature setpoint are < 54C
then the BLUE led is on.
// Otherwise the RED led is on. There is 1C hysteresis.
#ifndef TEMP_STAT_LEDS

// M240 Triggers a camera by emulating a Canon RC-1 Remote
// Data from: http://www.doc-diy.net/photo/rc-1_hacked/
#ifndef PHOTOGRAPH_PIN      23

// SkeinForge sends the wrong arc g-codes when using Arc Point as fillet
procedure
#ifndef SF_ARC_FIX

// Support for the BariCUDA Paste Extruder.
#ifndef BARICUDA

#define BlinkM/CyzRgb Support
#define BLINKM

*****
\
* R/C SERVO support
* Sponsored by TrinityLabs, Reworked by codexmas
*****
/

// Number of servos
//
// If you select a configuration below, this will receive a default value
and does not need to be set manually
// set it manually if you have more servos than extruders and wish to
manually control some
// leaving it undefined or defining as 0 will disable the servo subsystem
// If unsure, leave commented / disabled

```

```

//  

// #define NUM_SERVOS 3 // Servo index starts with 0 for M280 command  

// Delay (in microseconds) before the next move will start, to give the  

servo time to reach its target angle.  

// 300ms is a good value but you can try less delay.  

// If the servo can't reach the requested position, increase it.  

#define SERVO_DELAY 300  

// Servo deactivation  

//  

// With this option servos are powered only during movement, then turned  

off to prevent jitter.  

#define DEACTIVATE_SERVOS_AFTER_MOVE  

*****  

*\  

* Support for a filament diameter sensor  

* Also allows adjustment of diameter at print time (vs at slicing)  

* Single extruder only at this point (extruder 0)  

*  

* Motherboards  

* 34 - RAMPS1.4 - uses Analog input 5 on the AUX2 connector  

* 81 - Printrboard - Uses Analog input 2 on the Exp1 connector (version  

B,C,D,E)  

* 301 - Rambo - uses Analog input 3  

* Note may require analog pins to be defined for different motherboards  

*****  

/  

// Uncomment below to enable  

#define FILAMENT_WIDTH_SENSOR  

  

#define DEFAULT_NOMINAL_FILAMENT_DIA 3.00 //Enter the diameter (in mm)  

of the filament generally used (3.0 mm or 1.75 mm) - this is then used in  

the slicer software. Used for sensor reading validation  

  

#if ENABLED(FILAMENT_WIDTH_SENSOR)  

#define FILAMENT_SENSOR_EXTRUDER_NUM 0 //The number of the extruder  

that has the filament sensor (0,1,2)  

#define MEASUREMENT_DELAY_CM 14 //measurement delay in cm.  

This is the distance from filament sensor to middle of barrel  

  

#define MEASURED_UPPER_LIMIT 3.30 //upper limit factor used  

for sensor reading validation in mm  

#define MEASURED_LOWER_LIMIT 1.90 //lower limit factor for  

sensor reading validation in mm  

#define MAX_MEASUREMENT_DELAY 20 //delay buffer size in bytes  

(1 byte = 1cm) - limits maximum measurement delay allowable (must be larger  

than MEASUREMENT_DELAY_CM and lower number saves RAM)  

  

#define DEFAULT_MEASURED_FILAMENT_DIA DEFAULT_NOMINAL_FILAMENT_DIA

```

```
//set measured to nominal initially  
  
//When using an LCD, uncomment the line below to display the Filament  
sensor data on the last line instead of status. Status will appear for  
5 sec.  
 // #define FILAMENT_LCD_DISPLAY  
#endif  
  
#endif // CONFIGURATION_H
```