



















ITEM NO.	PART NUMBER	QTY.
1	upper pivoting tongue	1
2	lower_tongue (fixed)	1
3	string	1
4	upright	2
5	frame_top_block	1
6	belt_clamp_block	2
7	knob	4
8	indicator_mount	1
9	Dial_indicator_body- Harbor_Freight_Item623	1
10	Dial_indicator_body- Harbor_Freight_Item623	1
11	91247A632	1
12	92865A542	1
13	hinge_plate	2
14	99136A400	6
15	weight_hopper	1
16	belt	1