

```

#ifndef CONFIGURATION_H
#define CONFIGURATION_H

// This configuration file contains the basic settings.
// Advanced settings can be found in Configuration_adv.h
// BASIC SETTINGS: select your board type, temperature sensor type,
axis scaling, and endstop configuration

//
=====
=====
//===== DELTA Printer
=====
//
=====
=====
// For a Delta printer rplace the configuration files wilth the files
in the
// example_configurations/delta directory.
//

// User-specified version info of this build to display in
[Pronterface, etc] terminal window during
// startup. Implementation of an idea by Prof Braino to inform user
that any changes made to this
// build by the user have been successfully uploaded into firmware.
#define STRING_VERSION_CONFIG_H __DATE__ "05/8 RKT" __TIME__ // build
date and time
#define STRING_CONFIG_H_AUTHOR "(Richard Turnock, 3DR Simple March
2014)" // Who made the changes.

// SERIAL_PORT selects which serial port should be used for
communication with the host.
// This allows the connection of wireless adapters (for instance) to
non-default port pins.
// Serial port 0 is still used by the Arduino bootloader regardless of
this setting.
#define SERIAL_PORT 0

// This determines the communication speed of the printer
#define BAUDRATE 250000

// This enables the serial port associated to the Bluetooth interface
// #define BTENABLED // Enable BT interface on AT90USB
devices

///// The following define selects which electronics board you have.
Please choose the one that matches your setup
// 10 = Gen7 custom (Alfons3 Version) "https://github.com/Alfons3/

```

```

Generation_7_Electronics"
// 11 = Gen7 v1.1, v1.2 = 11
// 12 = Gen7 v1.3
// 13 = Gen7 v1.4
// 2 = Cheaptronic v1.0
// 20 = Sethi 3D_1
// 3 = MEGA/RAMPS up to 1.2 = 3
// 33 = RAMPS 1.3 / 1.4 (Power outputs: Extruder, Fan, Bed)
// 34 = RAMPS 1.3 / 1.4 (Power outputs: Extruder0, Extruder1, Bed)
// 35 = RAMPS 1.3 / 1.4 (Power outputs: Extruder, Fan, Fan)
// 4 = Duemilanove w/ ATmega328P pin assignment
// 5 = Gen6
// 51 = Gen6 deluxe
// 6 = Sanguinololu < 1.2
// 62 = Sanguinololu 1.2 and above
// 63 = Melzi
// 64 = STB V1.1
// 65 = Azteeg X1
// 66 = Melzi with ATmega1284 (MaKr3d version)
// 67 = Azteeg X3
// 7 = Ultimaker
// 71 = Ultimaker (Older electronics. Pre 1.5.4. This is rare)
// 77 = 3Drag Controller
// 8 = Teensylu
// 80 = Rumba
// 81 = Printrboard (AT90USB1286)
// 82 = Brainwave (AT90USB646)
// 83 = SAV Mk-I (AT90USB1286)
// 9 = Gen3+
// 70 = Megatronics
// 701= Megatronics v2.0
// 702= Minitronics v1.0
// 90 = Alpha OMCA board
// 91 = Final OMCA board
// 301 = Rambo
// 21 = Elefu Ra Board (v3)

#ifndef MOTHERBOARD
#define MOTHERBOARD 81 // RKT
#endif

// Define this to set a custom name for your generic Mendel,
#define CUSTOM_MENDEL_NAME "3DR Simple"

// Define this to set a unique identifier for this printer, (Used by
some programs to differentiate between machines)
// You can use an online service to generate a random UUID. (eg
http://www.uuidgenerator.net/version4)
#define MACHINE_UUID "e79f7d61-4868-460d-9fd7-261fd4325e5b"

```

```
// This defines the number of extruders
#define EXTRUDERS 1

//// The following define selects which power supply you have. Please
choose the one that matches your setup
// 1 = ATX
// 2 = X-Box 360 203Watts (the blue wire connected to PS_ON and the
red wire to VCC)

#define POWER_SUPPLY 1

// Define this to have the electronics keep the powersupply off on
startup. If you don't know what this is leave it.
// #define PS_DEFAULT_OFF

//
=====
=====
//===== Delta Settings
=====
//
=====
=====
// Enable DELTA kinematics and most of the default configuration for
Deltas
#define DELTA

// Make delta curves from many straight lines (linear interpolation).
// This is a trade-off between visible corners (not enough segments)
// and processor overload (too many expensive sqrt calls).
#define DELTA_SEGMENTS_PER_SECOND 100 // RKT verified that 100 gets
faster speeds

// NOTE NB all values for DELTA_* values MUST be floating point, so
always have a decimal point in them

// Center-to-center distance of the holes in the diagonal push rods.
#define DELTA_DIAGONAL_ROD 181.0 // mm RKT measured 215.0

// Horizontal offset from middle of printer to smooth rod center.
#define DELTA_SMOOTH_ROD_OFFSET (133.54-1.0) // mm RKT

// Horizontal offset of the universal joints on the end effector.
#define DELTA_EFFECTOR_OFFSET 22.87 // mm RKT

// Horizontal offset of the universal joints on the carriages.
#define DELTA_CARRIAGE_OFFSET 16.5 // mm RKT

// Effective horizontal distance bridged by diagonal push rods.
#define DELTA_RADIUS (DELTA_SMOOTH_ROD_OFFSET-DELTA_EFFECTOR_OFFSET-
```

```

DELTA_CARRIAGE_OFFSET) // RKT (133.54-1.0)-22.87-16.5=93.17

#define DELTA_DIAGONAL_ROD_2 sq(DELTA_DIAGONAL_ROD)

// Effective X/Y positions of the three vertical towers.
#define SIN_60 0.8660254037844386
#define COS_60 0.5
#define DELTA_TOWER1_X -SIN_60*DELTA_RADIUS // front left tower
#define DELTA_TOWER1_Y -COS_60*DELTA_RADIUS
#define DELTA_TOWER2_X SIN_60*DELTA_RADIUS // front right tower
#define DELTA_TOWER2_Y -COS_60*DELTA_RADIUS
#define DELTA_TOWER3_X 0.0 // back middle tower
#define DELTA_TOWER3_Y DELTA_RADIUS

//
=====
=====
//=====Thermal Settings
=====
//
=====
=====
//
//--NORMAL IS 4.7kohm PULLUP!-- 1kohm pullup can be used on hotend
sensor, using correct resistor and table
//
//// Temperature sensor settings:
// -2 is thermocouple with MAX6675 (only for sensor 0)
// -1 is thermocouple with AD595
// 0 is not used
// 1 is 100k thermistor - best choice for EPCOS 100k (4.7k pullup)
// 2 is 200k thermistor - ATC Semitec 204GT-2 (4.7k pullup)
// 3 is mendel-parts thermistor (4.7k pullup)
// 4 is 10k thermistor !! do not use it for a hotend. It gives bad
resolution at high temp. !!
// 5 is 100K thermistor - ATC Semitec 104GT-2 (Used in ParCan & J-
Head) (4.7k pullup)
// 6 is 100k EPCOS - Not as accurate as table 1 (created using a fluke
thermocouple) (4.7k pullup)
// 7 is 100k Honeywell thermistor 135-104LAG-J01 (4.7k pullup)
// 71 is 100k Honeywell thermistor 135-104LAF-J01 (4.7k pullup)
// 8 is 100k 0603 SMD Vishay NTCS0603E3104FXT (4.7k pullup)
// 9 is 100k GE Sensing AL03006-58.2K-97-G1 (4.7k pullup)
// 10 is 100k RS thermistor 198-961 (4.7k pullup)
// 60 is 100k Maker's Tool Works Kapton Bed Thermister
//
// 1k ohm pullup tables - This is not normal, you would have to
have changed out your 4.7k for 1k
// (but gives greater accuracy and more
stable PID)

```

```

// 51 is 100k thermistor - EPCOS (1k pullup)
// 52 is 200k thermistor - ATC Semitec 204GT-2 (1k pullup)
// 55 is 100k thermistor - ATC Semitec 104GT-2 (Used in ParCan & J-
Head) (1k pullup)

#define TEMP_SENSOR_0 5 // RKT
#define TEMP_SENSOR_1 0 // RKT
#define TEMP_SENSOR_2 0
#define TEMP_SENSOR_BED 0

// This makes temp sensor 1 a redundant sensor for sensor 0. If the
temperatures difference between these sensors is to high the print
will be aborted.
//#define TEMP_SENSOR_1_AS_REDUNDANT
#define MAX_REDUNDANT_TEMP_SENSOR_DIFF 10

// Actual temperature must be close to target for this long before
M109 returns success
#define TEMP_RESIDENCY_TIME 10 // (seconds)
#define TEMP_HYSTERESIS 3 // (degC) range of +/- temperatures
considered "close" to the target one
#define TEMP_WINDOW 1 // (degC) Window around target to
start the residency timer x degC early.

// The minimal temperature defines the temperature below which the
heater will not be enabled It is used
// to check that the wiring to the thermistor is not broken.
// Otherwise this would lead to the heater being powered on all the
time.
#define HEATER_0_MINTEMP 5
#define HEATER_1_MINTEMP 5
#define HEATER_2_MINTEMP 5
#define BED_MINTEMP 5

// When temperature exceeds max temp, your heater will be switched
off.
// This feature exists to protect your hotend from overheating
accidentally, but *NOT* from thermistor short/failure!
// You should use MINTEMP for thermistor short/failure protection.
#define HEATER_0_MAXTEMP 275
#define HEATER_1_MAXTEMP 275
#define HEATER_2_MAXTEMP 275
#define BED_MAXTEMP 150

// If your bed has low resistance e.g. .6 ohm and throws the fuse you
can duty cycle it to reduce the
// average current. The value should be an integer and the heat bed
will be turned on for 1 interval of
// HEATER_BED_DUTY_CYCLE_DIVIDER intervals.
//#define HEATER_BED_DUTY_CYCLE_DIVIDER 4

```

```

// PID settings:
// Comment the following line to disable PID and enable bang-bang.
#define PIDTEMP
#define BANG_MAX 255 // limits current to nozzle while in bang-bang
mode; 255=full current
#define PID_MAX 255 // limits current to nozzle while PID is active
(see PID_FUNCTIONAL_RANGE below); 255=full current was 190 RKT
#ifdef PIDTEMP
  //#define PID_DEBUG // Sends debug data to the serial port.
  //#define PID_OPENLOOP 1 // Puts PID in open loop. M104/M140 sets
the output power from 0 to PID_MAX
  #define PID_FUNCTIONAL_RANGE 10 // If the temperature difference
between the target temperature and the actual temperature
// is more then PID_FUNCTIONAL_RANGE
then the PID will be shut off and the heater will be set to min/max.
  #define PID_INTEGRAL_DRIVE_MAX 255 //limit for the integral term
  #define K1 0.95 //smoothing factor within the PID
  #define PID_dT ((16.0 * 8.0)/(F_CPU / 64.0 / 256.0)) //sampling
period of the temperature routine

// If you are using a preconfigured hotend then you can use one of the
value sets by uncommenting it
// Ultimaker
//RKT E3D hot end
  #define DEFAULT_Kp 22.2
  #define DEFAULT_Ki 1.08
  #define DEFAULT_Kd 114

// Makergear
//   #define DEFAULT_Kp 7.0
//   #define DEFAULT_Ki 0.1
//   #define DEFAULT_Kd 12

// Mendel Parts V9 on 12V
//   #define DEFAULT_Kp 63.0
//   #define DEFAULT_Ki 2.25
//   #define DEFAULT_Kd 440
#endif // PIDTEMP

// Bed Temperature Control
// Select PID or bang-bang with PIDTEMPBED. If bang-bang,
BED_LIMIT_SWITCHING will enable hysteresis
//
// Uncomment this to enable PID on the bed. It uses the same frequency
PWM as the extruder.
// If your PID_dT above is the default, and correct for your hardware/
configuration, that means 7.689Hz,
// which is fine for driving a square wave into a resistive load and
does not significantly impact you FET heating.

```

```

// This also works fine on a Fotek SSR-10DA Solid State Relay into a
// 250W heater.
// If your configuration is significantly different than this and you
// don't understand the issues involved, you probably
// shouldn't use bed PID until someone else verifies your hardware
// works.
// If this is enabled, find your own PID constants below.
//#define PIDTEMPBED
//
//#define BED_LIMIT_SWITCHING

// This sets the max power delivered to the bed, and replaces the
// HEATER_BED_DUTY_CYCLE_DIVIDER option.
// all forms of bed control obey this (PID, bang-bang, bang-bang with
// hysteresis)
// setting this to anything other than 255 enables a form of PWM to
// the bed just like HEATER_BED_DUTY_CYCLE_DIVIDER did,
// so you shouldn't use it unless you are OK with PWM on your bed.
// (see the comment on enabling PIDTEMPBED)
#define MAX_BED_POWER 255 // limits duty cycle to bed; 255=full
// current

#ifdef PIDTEMPBED
//120v 250W silicone heater into 4mm borosilicate (MendelMax 1.5+)
//from FOPDT model - kp=.39 Tp=405 Tdead=66, Tc set to 79.2,
//aggressive factor of .15 (vs .1, 1, 10)
    #define DEFAULT_bedKp 10.00
    #define DEFAULT_bedKi .023
    #define DEFAULT_bedKd 305.4

//120v 250W silicone heater into 4mm borosilicate (MendelMax 1.5+)
//from pidautotune
//    #define DEFAULT_bedKp 97.1
//    #define DEFAULT_bedKi 1.41
//    #define DEFAULT_bedKd 1675.16

// FIND YOUR OWN: "M303 E-1 C8 S90" to run autotune on the bed at 90
// degreesC for 8 cycles.
#endif // PIDTEMPBED

//this prevents dangerous Extruder moves, i.e. if the temperature is
//under the limit
//can be software-disabled for whatever purposes by
#define PREVENT_DANGEROUS_EXTRUDE
//if PREVENT_DANGEROUS_EXTRUDE is on, you can still disable
// (uncomment) very long bits of extrusion separately.
#define PREVENT_LENGTHY_EXTRUDE

```

```

#define EXTRUDE_MINTEMP 170
#define EXTRUDE_MAXLENGTH (X_MAX_LENGTH+Y_MAX_LENGTH) //prevent
extrusion of very large distances.

//
=====
=====
//=====Mechanical
Settings=====
//
=====
=====

// Uncomment the following line to enable CoreXY kinematics
// #define COREXY

// coarse Endstop Settings
#define ENDSTOPPULLUPS // Comment this out (using // at the start of
the line) to disable the endstop pullup resistors

#ifndef ENDSTOPPULLUPS
  // fine Enstop settings: Individual Pullups. will be ignored if
  ENDSTOPPULLUPS is defined
  // #define ENDSTOPPULLUP_XMAX
  // #define ENDSTOPPULLUP_YMAX
  // #define ENDSTOPPULLUP_ZMAX
  // #define ENDSTOPPULLUP_XMIN
  // #define ENDSTOPPULLUP_YMIN
  // #define ENDSTOPPULLUP_ZMIN
#endif

#ifdef ENDSTOPPULLUPS
  #define ENDSTOPPULLUP_XMAX
  #define ENDSTOPPULLUP_YMAX
  #define ENDSTOPPULLUP_ZMAX
  #define ENDSTOPPULLUP_XMIN
  #define ENDSTOPPULLUP_YMIN
  #define ENDSTOPPULLUP_ZMIN
#endif

// The pullups are needed if you directly connect a mechanical
endswitch between the signal and ground pins.
const bool X_MIN_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT
const bool Y_MIN_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT
const bool Z_MIN_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT
const bool X_MAX_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT

```



```

const bool Y_MAX_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT
const bool Z_MAX_ENDSTOP_INVERTING = false; // set to true to invert
the logic of the endstop. RKT
///

```

```

#define X_MAX_POS 90
#define X_MIN_POS -90
#define Y_MAX_POS 90
#define Y_MIN_POS -90
#define Z_MAX_POS MANUAL_Z_HOME_POS
#define Z_MIN_POS 0

#define X_MAX_LENGTH (X_MAX_POS - X_MIN_POS)
#define Y_MAX_LENGTH (Y_MAX_POS - Y_MIN_POS)
#define Z_MAX_LENGTH (Z_MAX_POS - Z_MIN_POS)
//===== Bed Auto Leveling
=====

//#define ENABLE_AUTO_BED_LEVELING // Delete the comment to enable
(remove // at the start of the line)

#ifdef ENABLE_AUTO_BED_LEVELING

    // these are the positions on the bed to do the probing
    #define LEFT_PROBE_BED_POSITION 15
    #define RIGHT_PROBE_BED_POSITION 170
    #define BACK_PROBE_BED_POSITION 180
    #define FRONT_PROBE_BED_POSITION 20

    // these are the offsets to the prob relative to the extruder tip
    (Hotend - Probe)
    #define X_PROBE_OFFSET_FROM_EXTRUDER -25
    #define Y_PROBE_OFFSET_FROM_EXTRUDER -29
    #define Z_PROBE_OFFSET_FROM_EXTRUDER -12.35

    #define Z_RAISE_BEFORE_HOMING 4 // (in mm) Raise Z before
    homing (G28) for Probe Clearance. // Be sure you have this
    distance over your Z_MAX_POS in case

    #define XY_TRAVEL_SPEED 8000 // X and Y axis travel speed
    between probes, in mm/min

    #define Z_RAISE_BEFORE_PROBING 15 //How much the extruder will be
    raised before traveling to the first probing point.
    #define Z_RAISE_BETWEEN_PROBINGS 5 //How much the extruder will be
    raised when traveling from between next probing points

    //If defined, the Probe servo will be turned on only during movement
    and then turned off to avoid jerk
    //The value is the delay to turn the servo off after powered on -
    depends on the servo speed; 300ms is good value, but you can try lower
    it.
    // You MUST HAVE the SERVO_ENDSTOPS defined to use here a value

```

higher than zero otherwise your code will not compile.

```
// #define PROBE_SERVO_DEACTIVATION_DELAY 300
```

```
//If you have enabled the Bed Auto Levelling and are using the same Z  
Probe for Z Homing,  
//it is highly recommended you let this Z_SAFE_HOMING enabled!!!
```

```
#define Z_SAFE_HOMING // This feature is meant to avoid Z homing  
with probe outside the bed area.  
// When defined, it will:  
// - Allow Z homing only after X and Y  
homing AND stepper drivers still enabled  
// - If stepper drivers timeout, it will  
need X and Y homing again before Z homing  
// - Position the probe in a defined XY  
point before Z Homing when homing all axis (G28)  
// - Block Z homing only when the probe is  
outside bed area.
```

```
#ifndef Z_SAFE_HOMING
```

```
#define Z_SAFE_HOMING_X_POINT (X_MAX_LENGTH/2) // X point for Z  
homing when homing all axis (G28)  
#define Z_SAFE_HOMING_Y_POINT (Y_MAX_LENGTH/2) // Y point for Z  
homing when homing all axis (G28)
```

```
#endif
```

```
#endif
```

```
// The position of the homing switches  
//#define MANUAL_HOME_POSITIONS // If defined, MANUAL_*_HOME_POS  
below will be used  
//#define BED_CENTER_AT_0_0 // If defined, the center of the bed is  
at (X=0, Y=0)
```

```
//Manual homing switch locations:
```

```
#define MANUAL_HOME_POSITIONS // MANUAL_*_HOME_POS below will be used  
// For deltabots this means top and center of the cartesian print  
volume.  
#define MANUAL_X_HOME_POS 0  
#define MANUAL_Y_HOME_POS 0  
#define MANUAL_Z_HOME_POS 222.0 // For 3DR Simple delta: Distance  
between nozzle and print surface after homing.
```

```
//// MOVEMENT SETTINGS
```

```

#define NUM_AXIS 4 // The axis order in all axis related arrays is X,
Y, Z, E

// delta homing speeds must be the same on xyz
#define HOMING_FEEDRATE {80*60, 80*60, 80*60, 0} // set the homing
speeds (mm/min) RKT was 100*60

// default settings
// delta speeds must be the same on xyz
#define DEFAULT_AXIS_STEPS_PER_UNIT {55.5, 55.5, 55.5, 260} //
default steps per unit for 3DR Simple with Spectra line 55.5 per
RichRap

//
Extruder Greg's Wade geared 44:13 1/16 stepping estimate 260-290
#define DEFAULT_MAX_FEEDRATE {5000, 5000, 5000, 29} //
(mm/sec) RKT changed extruder max feedrate per RichRapis 32 but uses
29

// RichRap
started with 380 and now uses 500 but changed to 200 for testing
#define DEFAULT_MAX_ACCELERATION {4000,4000,4000,10000} // X,
Y, Z, E maximum start speed for accelerated moves.
// Jan 26 was DEFAULT_MAX_ACCELERATION {9000,9000,9000,10000}
// E default values are good for skeinforge 40+, for older versions
raise them a lot.

#define DEFAULT_ACCELERATION 380 // X, Y, Z and E max
acceleration in mm/s^2 for printing moves. RichRap value 380, 300 OK
could go 10X faster
#define DEFAULT_RETRACT_ACCELERATION 380 // X, Y, Z and E max
acceleration in mm/s^2 for retracts. same as above

// Offset of the extruders (uncomment if using more than one and
relying on firmware to position when changing).
// The offset has to be X=0, Y=0 for the extruder 0 hotend (default
extruder).
// For the other hotends it is their distance from the extruder 0
hotend.
// #define EXTRUDER_OFFSET_X {0.0, 20.00} // (in mm) for each
extruder, offset of the hotend on the X axis
// #define EXTRUDER_OFFSET_Y {0.0, 5.00} // (in mm) for each
extruder, offset of the hotend on the Y axis

// The speed change that does not require acceleration (i.e. the
software might assume it can be done instantaneously)
#define DEFAULT_XYJERK 20.0 // (mm/sec)
#define DEFAULT_ZJERK 20.0 // (mm/sec) Must be same
as XY for delta
#define DEFAULT_EJERK 20.0 // (mm/sec) set all
the same for Delta

```

```

//
=====
=====
//=====Additional
Features=====
//
=====
=====

// EEPROM
// the microcontroller can store settings in the EEPROM, e.g. max
velocity...
// M500 - stores paramters in EEPROM
// M501 - reads parameters from EEPROM (if you need reset them after
you changed them temporarily).
// M502 - reverts to the default "factory settings". You still need
to store them in EEPROM afterwards if you want to.
//define this to enable eeprom support
#define EEPROM_SETTINGS
//to disable EEPROM Serial responses and decrease program space by
~1700 byte: comment this out:
// please keep turned on if you can.
#define EEPROM_CHITCHAT

// Preheat Constants
#define PLA_PREHEAT_HOTEND_TEMP 180
#define PLA_PREHEAT_HPB_TEMP 70
#define PLA_PREHEAT_FAN_SPEED 255 // Insert Value between 0 and 255

#define ABS_PREHEAT_HOTEND_TEMP 240
#define ABS_PREHEAT_HPB_TEMP 100
#define ABS_PREHEAT_FAN_SPEED 255 // Insert Value between 0 and 255

//LCD and SD support
//#define ULTRA_LCD //general lcd support, also 16x2 RKT
//#define DOGLCD // Support for SPI LCD 128x64 (Controller ST7565R
graphic Display Family)
//#define SDSUPPORT // Enable SD Card Support in Hardware Console RKT
//#define SDSLOW // Use slower SD transfer mode (not normally needed -
uncomment if you're getting volume init error)
//#define ENCODER_PULSES_PER_STEP 1 // Increase if you have a high
resolution encoder
//#define ENCODER_STEPS_PER_MENU_ITEM 5 // Set according to
ENCODER_PULSES_PER_STEP or your liking
//#define ULTIMAKERCONTROLLER //as available from the ultimaker online
store.
//#define NEWPANEL //RKT
//#define ULTIPANEL //the ultipanel as on thingiverse RKT

```

```

// The MaKr3d Makr-Panel with graphic controller and SD support
// http://reprap.org/wiki/MaKr3d_MaKrPanel
//#define MAKRPANEL

// The RepRapDiscount Smart Controller (white PCB)
// http://reprap.org/wiki/RepRapDiscount_Smart_Controller
//#define REPRAP_DISCOUNT_SMART_CONTROLLER

// The GADGETS3D G3D LCD/SD Controller (blue PCB)
// http://reprap.org/wiki/RAMPS_1.3/1.4_GADGETS3D_Shield_with_Panel
//#define G3D_PANEL

// The RepRapDiscount FULL GRAPHIC Smart Controller (quadratic white
PCB)
// http://reprap.org/wiki/RepRapDiscount_Full_Graphic_Smart_Controller
//
// ==> REMEMBER TO INSTALL U8glib to your ARDUINO library folder:
http://code.google.com/p/u8glib/wiki/u8glib
//#define REPRAP_DISCOUNT_FULL_GRAPHIC_SMART_CONTROLLER

// The RepRapWorld REPRAPWORLD_KEYPAD v1.1
// http://reprapworld.com/?
products_details&products_id=202&cPath=1591_1626
//#define REPRAPWORLD_KEYPAD
//#define REPRAPWORLD_KEYPAD_MOVE_STEP 10.0 // how much should be
moved when a key is pressed, eg 10.0 means 10mm per click

// The Elefu RA Board Control Panel
// http://www.elefu.com/index.php?route=product/product&product_id=53
// REMEMBER TO INSTALL LiquidCrystal_I2C.h in your ARUDINO library
folder: https://github.com/kiyoshigawa/LiquidCrystal_I2C
//#define RA_CONTROL_PANEL

//automatic expansion
#if defined (MAKRPANEL)
  #define DOGLCD
  #define SDSUPPORT
  #define ULTIPANEL
  #define NEWPANEL
  #define DEFAULT_LCD_CONTRAST 17
#endif

#if defined (REPRAP_DISCOUNT_FULL_GRAPHIC_SMART_CONTROLLER)
  #define DOGLCD
  #define U8GLIB_ST7920
  #define REPRAP_DISCOUNT_SMART_CONTROLLER
#endif

#if defined(ULTIMAKERCONTROLLER) ||
defined(REPRAP_DISCOUNT_SMART_CONTROLLER) || defined(G3D_PANEL)

```

```

#define ULTIPANEL
#define NEWPANEL
#endif

#if defined(REPRAPWORLD_KEYPAD)
#define NEWPANEL
#define ULTIPANEL
#endif
#if defined(RA_CONTROL_PANEL)
#define ULTIPANEL
#define NEWPANEL
#define LCD_I2C_TYPE_PCA8574
#define LCD_I2C_ADDRESS 0x27 // I2C Address of the port expander
#endif

//I2C PANELS

//#define LCD_I2C_SAINSMART_YWROBOT
#ifndef LCD_I2C_SAINSMART_YWROBOT
// This uses the LiquidCrystal_I2C library ( https://bitbucket.org/
fmalpartida/new-liquidcrystal/wiki/Home )
// Make sure it is placed in the Arduino libraries directory.
#define LCD_I2C_TYPE_PCF8575
#define LCD_I2C_ADDRESS 0x27 // I2C Address of the port expander
#define NEWPANEL
#define ULTIPANEL
#endif

// PANEL0LU2 LCD with status LEDs, separate encoder and click inputs
//#define LCD_I2C_PANEL0LU2
#ifndef LCD_I2C_PANEL0LU2
// This uses the LiquidTWI2 library v1.2.3 or later ( https://
github.com/lincomatic/LiquidTWI2 )
// Make sure the LiquidTWI2 directory is placed in the Arduino or
Sketchbook libraries subdirectory.
// (v1.2.3 no longer requires you to define PANEL0LU in the
LiquidTWI2.h library header file)
// Note: The PANEL0LU2 encoder click input can either be directly
connected to a pin
// (if BTN_ENC defined to != -1) or read through I2C (when
BTN_ENC == -1).
#define LCD_I2C_TYPE_MCP23017
#define LCD_I2C_ADDRESS 0x20 // I2C Address of the port expander
#define LCD_USE_I2C_BUZZER //comment out to disable buzzer on LCD
#define NEWPANEL
#define ULTIPANEL
#endif

// Panucatt VIKI LCD with status LEDs, integrated click & L/R/U/P
buttons, separate encoder inputs

```

```

//#define LCD_I2C_VIKI
#ifdef LCD_I2C_VIKI
  // This uses the LiquidTWI2 library v1.2.3 or later ( https://
  github.com/lincomatic/LiquidTWI2 )
  // Make sure the LiquidTWI2 directory is placed in the Arduino or
  Sketchbook libraries subdirectory.
  // Note: The pause/stop/resume LCD button pin should be connected to
  the Arduino
  //      BTN_ENC pin (or set BTN_ENC to -1 if not used)
  #define LCD_I2C_TYPE_MCP23017
  #define LCD_I2C_ADDRESS 0x20 // I2C Address of the port expander
  #define LCD_USE_I2C_BUZZER //comment out to disable buzzer on LCD
  (requires LiquidTWI2 v1.2.3 or later)
  #define NEWPANEL
  #define ULTIPANEL
#endif

// Shift register panels
// -----
// 2 wire Non-latching LCD SR from:
// https://bitbucket.org/fmalpartida/new-liquidcrystal/wiki/
// schematics#!shiftregister-connection
//#define SR_LCD
#ifdef SR_LCD
  #define SR_LCD_2W_NL // Non latching 2 wire shiftregister
  // #define NEWPANEL
#endif

#ifdef ULTIPANEL
  // #define NEWPANEL //enable this if you have a click-encoder panel
  #define SDSUPPORT
  #define ULTRA_LCD
  #ifndef DOGLCD // Change number of lines to match the DOG graphic
  display
    #define LCD_WIDTH 20
    #define LCD_HEIGHT 5
  #else
    #define LCD_WIDTH 20
    #define LCD_HEIGHT 4
  #endif
#else //no panel but just lcd
  #ifndef ULTRA_LCD
    #ifndef DOGLCD // Change number of lines to match the 128x64 graphics
    display
      #define LCD_WIDTH 20
      #define LCD_HEIGHT 5
    #else
      #define LCD_WIDTH 16
      #define LCD_HEIGHT 2
    #endif
  #endif

```



```

    #endif
  #endif
#endif

// default LCD contrast for dogm-like LCD displays
#ifndef DOGLCD
# ifndef DEFAULT_LCD_CONTRAST
#  define DEFAULT_LCD_CONTRAST 32
# endif
#endif

// Increase the FAN pwm frequency. Removes the PWM noise but increases
heating in the FET/Arduino
//#define FAST_PWM_FAN

// Temperature status leds that display the hotend and bed
temperature.
// If alle hotends and bed temperature and temperature setpoint are <
54C then the BLUE led is on.
// Otherwise the RED led is on. There is 1C hysteresis.
//#define TEMP_STAT_LEDS

// Use software PWM to drive the fan, as for the heaters. This uses a
very low frequency
// which is not ass annoying as with the hardware PWM. On the other
hand, if this frequency
// is too low, you should also increment SOFT_PWM_SCALE.
//#define FAN_SOFT_PWM

// Incrementing this by 1 will double the software PWM frequency,
// affecting heaters, and the fan if FAN_SOFT_PWM is enabled.
// However, control resolution will be halved for each increment;
// at zero value, there are 128 effective control positions.
#define SOFT_PWM_SCALE 0

// M240 Triggers a camera by emulating a Canon RC-1 Remote
// Data from: http://www.doc-diy.net/photo/rc-1\_hacked/
// #define PHOTOGRAPH_PIN    23

// SF send wrong arc g-codes when using Arc Point as fillet procedure
//#define SF_ARC_FIX

// Support for the BariCUDA Paste Extruder.
//#define BARICUDA

//define BlinkM/CyzRgb Support
//#define BLINKM

/*****
\

```

```
* R/C SERVO support
* Sponsored by TrinityLabs, Reworked by codexmas
*****
/

// Number of servos
//
// If you select a configuration below, this will receive a default
value and does not need to be set manually
// set it manually if you have more servos than extruders and wish to
manually control some
// leaving it undefined or defining as 0 will disable the servo
subsystem
// If unsure, leave commented / disabled
//
//#define NUM_SERVOS 3 // Servo index starts with 0 for M280 command

// Servo Endstops
//
// This allows for servo actuated endstops, primary usage is for the Z
Axis to eliminate calibration or bed height changes.
// Use M206 command to correct for switch height offset to actual
nozzle height. Store that setting with M500.
//
//#define SERVO_ENDSTOPS {-1, -1, 0} // Servo index for X, Y, Z.
Disable with -1
//#define SERVO_ENDSTOP_ANGLES {0,0, 0,0, 70,0} // X,Y,Z Axis Extend
and Retract angles

#include "Configuration_adv.h"
#include "thermistortables.h"

#endif //__CONFIGURATION_H
```