


Open the layout in PCB.



- Switch to the "GND-sldr" layer.
- Remove all tracks on this layer (= all light blue ones = all of the GND net minus vias and bridges, find the net with Menu -> Window -> Netlist).
- Draw a RECT (find the tool in the left bar) as big as the entire board.
- Do an "optimize rats nest" (o-key).

Net Name

- +5V
- +5VSB
- GND
- * unnamed_net1
- * unnamed_net10
- * unnamed_net11
- * unnamed_net12
- * unnamed_net13
- * unnamed_net14
- * unnamed_net15
- * unnamed_net16
- * unnamed_net17
- * unnamed_net18
- * unnamed_net19
- * unnamed_net2
- * unnamed_net20
- * unnamed_net21
- * unnamed_net22
- * unnamed_net23
- * unnamed_net24
- * unnamed_net25
- * unnamed_net26
- * unnamed_net27
- * unnamed_net28
- * unnamed_net29
- * unnamed_net3
- * unnamed_net30

Nodes

- C11-2
- C12-2
- C13-2
- C17-2
- C6-1
- CONN1-19
- CONN1-20
- CONN2-4
- J13-1
- R10-1
- R18-1
- R2-1
- R6-1
- R8-1
- U2-10
- U3-10
- U4-10
- U5-10
- X_MIN-3
- Y_MIN-3
- Z_MIN-3

Operations on selected 'Net Name':

- Select
- Unselect
- Find
- Rip Up

Disable all nets for adding rats

Close

- solder
- GND-sldr
- Vcc-sldr
- Text-sldr
- component
- outline
- silk
- rat lines
- pins/pads
- vias
- far side
- solder mask

